
AIRGAP

VALVE TO PEDAL CONNECTION (SEE FIG. 2)

 Connect 3.5mm Female Cable from the valve to the 3.5mm Male Cable on the pedal. See pedal installation on manual for the pedal.


FIG. 2



CAUTION:

AG250-003 Valve is battery operated (AA type, 4pcs included) Change battery instruction.

- 1. Disconnect cable connection between battery pack and valve.
- 2. Remove Battery pack from valve body.
- Open battery pack by removing a screw on the bottom of battery pack.
- 4. Replace batteries, following "+" and "_" sign.
- Close battery pack by installing the screw. Install battery pack into valve unit in original place. Squeeze metal tab if needed to hold battery pack in place.
- Connect 2.5 mm power plug cable from battery pack to 2.5mm power jack on the valve body (see FIG 3.)






Copyright 2019 AIR GAP INTERNATIONAL

Model: AG250-003

TAP-A-TAP™ COLD/HOT POTABLE WATER ELECTRICAL VALVE



Part No. AG250-003

Doc. # 400-0787-003

Installation Procedures

LIST OF PARTS ENCLOSED


2 – #8 Mounting Screws

1 - Hot/Cold Water Valve

2 - Drywall Twist In Lock Anchors

2 - Block and Brick Wall Anchors


2 - 30" Water Supply Hoses, connector 1/2" FIP x 1/2" FIP



The AG250-003, in combination with AG250 series foot pedals, provides hands free faucet operation. Pedals are ordered separately. Select from the following three foot pedals: AG250-403, AG250-503 or AG250-603.

Please read the instructions once through before starting.

VALVE INSTALLATION INSTRUCTIONS



AG250 Series Foot Pedals




Kitchen pedal with constant flow lock

Kitchen / bathroom pedal

Kitchen / bathroom floor mounted pedal

- Before mounting the AG250-003 make sure that water is turned off. Disconnect hoses (hot and cold water) between the faucet and water supply.
- Mount the AG250-003 valve to the wall in shown on FIG.1 position.
 Use supplied screws and anchors to mount valve. Install them in mounting openings on opposite corner of the unit (use 6mm/ 1/4" drill).
- 3. Connect valve's outlet ports to the faucet using provided 30" hoses.
- 4. Connect the water supply hoses to the inlet ports .
- 5. While connecting hoses to the valve, use minimum force to tighten the nut in order to prevent port adapter from rotating.
- 6. Connect 2.5 mm power plug cable from the battery pack to the 2.5mm power jack on the valve body (see FIG 1.)
- 6. Connect 3.5mm Female cable from the valve body to the pedal (see Fig. 1 and Fig. 2).
- 7. Turn on water supply and check for leakage.
- 8. Press the pedal, open the faucet, and adjust it to the desired water temperature and flow rate.
- 9. As long as the pedal is depressed, water will flow from the faucet.
- 10. When the pedal is released, the water flow stops.





Press the pedal on right side to lock in open position, open the faucet, and adjust it to the desired water temperature and flow rate.


As long as the pedal is pressed, water will flow from the faucet.

To release the pedal, press on the left side.

When the pedal is released, the water flow stops.



TAP-A-TAP™ KITCHEN PEDAL WITH CONSTANT FLOW LOCK STAINLESS STEEL FINISH



Part No.


AG250-403



Copyright 2019 AIR GAP INTERNATIONAL

AG250-403

Installation Procedures



Please read the instructions once through before starting.

PEDAL INSTALLATION INSTRUCTIONS

1. Place top mounting plate at the edge of the cabinet and mark location of mounting screws. Drill two holes for #10 screws. (13/64"). (FIG.1)

Drill hole 3/8" under the cabinet plate for cable connection to the valve. (FIG.1)




FIG. 1

3. Use provided #10 screws to attach pedal. (FIG.3)




FIG. 3

- 2. Pass cable from the AG250-403 pedal through the 3/8" opening under the cabinet plate and connect it to the AG250-003 valve installed inside the cabinet. (FIG.2)

FIG. 2

Pedal position can be adjusted using four screws on side of pedal assembly. (FIG.4)




FIG.4